



## Unique Touch Installation Instructions

**PLEASE READ SAFETY WARNINGS AND INSTALLATION INSTRUCTIONS PRIOR TO INSTALLATION.**

**FOR MAXIMUM SAFETY REASONS ALL SCREWS MUST BE MOUNTED INTO WOOD BLOCKING.**

1. Read all safety warnings before installation.
2. Measure the distance between center to center of the two mounting holes at each end of the grab bar. Choose the location for the grab bar on the wall using a measuring tape and a level for perfect horizontal or vertical mounting.
3. Be sure to check center to center measurements before drilling holes.
4. Drill two 1/8" holes having the same center-to center distance as the bar.
5. Beginning with the first hole, place the insert (4) and washer (5) onto the screw (3).
6. Insert the screw into the wall and tighten until the assembly is firmly supported; make sure to center the washer.
7. Repeat steps 3 and 4 for the second hole.
8. Install the grab bar on the insert and ensure the mount is firm. If additional adjustment is necessary, loosen the screw and reposition the insert in an easy way to be entered into the grab bar.
9. Insert Allen Screw (1) in the hole located under the handle until the screw touches the insert.  
**STOP SCREWING WHEN THE SCREW TOUCHES THE INSERT.** Do not force the screw or over tighten- the acrylic will crack.

